

Ocean Series Gold & Silver Bar Melting and Casting Machine



Ocean Series Gold & Silver Bar Melting and Casting Machine

Product Features:

Ocean Series IC1000 Gold Bar Machine is for Casting 1kg Gold Bar or Silver Bar. Put the graphite ingot mould into the melting chamber here is vacuum and protective air in melting and cooling process to avoid metal and graphite ingot oxidation. Protective gas can be argon or nitrogen.

Technical Parameters :

| | |
|-------------------------------------|------------------------|
| Model | ZMCMICI1000 |
| Power Supply | 220V,380V,3P,50/60HZ |
| Size of Graphite Ingot Mould | 1kg,500g,250g,100g,50g |
| Ingot Casting Method | Vacuum ingot |
| Cooling Way | Water Cooling |
| Size | 600x560x950 mm |
| Weight | 120 kg |