



Platinum Melting Machine Intermediate Frequency Induction Melting Furnance

Apply big power high frequency induction heating method to melt platinum or palladium. High frequency power not only provide fast melting but also electromagnetic mixing function which helps making highly even metal liquid.

This furnace is easy operation, convenient maintenance , reliable quality, safety working. It eliminates the problems of high noisy, operation hazards, and metal liquid splash and big wastage resulted by traditional oxgen gas melting, what's more, this high frequency melting furnace is harmless to human body, fast melting speed effectively improve your production efficiency.

Specification: 1kg, 2kg
Model: M.MF.P0001:M.MF.P0002
Specification: 1kg, 2kg
Power supply: 380V/50/60hz
Melting capacity: 1kg,2kg
Size: 500*680*1050mm
Weight: 68kg



**Ceramic Crucible
(1kg platinum melting
furnace space parts)**
Model: C.CM.B1000
Specification: Φ60*H99mm



**Ceramic Crucible
(2kg platinum melting
furnace space parts)**
Model: C.CM.B2000
Specification: Φ85xΦ70xH120mm
Weight: 500g