



OCEAN King India

Home of Quality Products



Precious Metal Purity Tester QL 3000K Capacity

Detailed Product Description :

- The maximum weight 3000g
- Weighing precision 0.06g
- Density precision 0.01g/cm³
- Water tank size 220*180*140mm

- The length of water tank can be customized

Principle :

According to the buoyancy method of Archimedeian principle, can show gold karat, density and purity % rapidly and accurately

Suitable For :

Jewelry industry ,bank,Pawn industry ,Gold and Precious Metal research lab.

Functions:

Only two weighing steps, the purity% of precious metals and gold karat can be showed rapidly and accurately. With the special software design, it can directly and circularly show the gold karat (including goldcoppersilver, gold-silver, gold-copper), gold purity% (including gold-copper-silver,gold-silver, goldcopper).

Contact Address :

Ocean King International
6213/B, St. No.-4, Hargobind Nagar,
Ludhiana, India 141008.

Sales and Support:

Tel : +91-161-5049059, 2222471
Email: info@oceankingindia.com, amitsood24@gmail.com
website: www.oceankingindia.com, www.goldtester.co



OCEAN King India

Home of Quality Products

With the function of HI and LO limit, the wide karat range from 9K to 24K and the data of HI and LO can be set freely.

No stains and scratches left on gold after testing, it doesn't need to use the sulfuric acid solution to test the standard samples.

Can't test the samples inlaid precious stones and hollow samples. It can be used as general balance.

By adopting the design of big tank, it can decrease the inaccuracy caused by supporting wire's buoyancy

Contact Address :

Ocean King International
6213/B, St. No.-4, Hargobind Nagar,
Ludhiana, India 141008.

Sales and Support:

Tel : +91-161-5049059, 2222471

Email: info@oceankingindia.com, amitsood24@gmail.com
website: www.oceankingindia.com, www.goldtester.co