



OCEAN King India
Home of Quality Products

Ocean Series Mini Induction Melting Machine MFML001



Brief Introduction

Ocean brand mini induction melting furnace is an advanced machine to melt gold, silver, brass and other precious metal.

Technical Parameters

- Model: Ocean Series Mini. MF.ML001
- Input Power: 220V/50~60Hz single phase
- Output Power: Around 3KW
- Suitable Metals: Gold, Silver, Brass etc.
- Melting Capacity: 1-2KG Gold
- Melting Time: 3-5 Mins.
- Max Temperature: 1450° E
- Water Cooling: Running water or water chiller
- Outline Size: 580x330x300MM
- Net Weight: 28KG

Contact Address :

Ocean King International
6213/B, St. No.-4, Hargobind Nagar,
Ludhiana, India 141008.

Sales and Support:

Tel : +91-161-5049059, 2222471

Email: info@oceankingindia.com, amitsood24@gmail.com
website: www.oceankingindia.com, www.goldtester.co



The Features

- Use famous brand INFINEON IGBT controller, has a stronger and more steady output power.
- With various protection as over voltage protection, over current protection, insufficient water protection, over heating protection. Safe and reliable.
- Quick temp rising, electricity saving, low melting cost with high cast efficiency.
- Desktop design, compact small size, light weight, easy operation, simple and convenient maintenance.
- 100% full load, 24 hours continuous working.
- This furnace adopts big power medium frequency induction melting way, fast heating speed, electromagnetic stirring function to get liquid metal with more even temperature and composition.

M.MF.ML001	1 Set	
G.GM.1000A	1 pc	
C.CC.1000A	1 pc	
/	1 pc	



Contact Address :

Ocean King International
6213/B, St. No.-4, Hargobind Nagar,
Ludhiana, India 141008.

Sales and Support:

Tel : +91-161-5049059, 2222471

Email: info@oceankingindia.com, amitsood24@gmail.com
website: www.oceankingindia.com, www.goldtester.co